

INSERT PUMP INTO SIDE INTAKE



Step-1: Confirm all items are in box.



Step-2: Remove filter screen from PUMP.



Step-3: Apply mineral oil to lip of rubber cup.



Step-4: Ensure alignment of intake will avoid any obstructions.



Step-5: Using weight of PUMP push into rubber cup to first radius as shown.



Step-6: Complete assembly of hose-line to side intake.

INSTRUCTION MANUAL

INSTRUCTION MANUAL

INSTRUCTION MANUAL

INSTRUCTION MANUAL