



DETAIL A
SCALE 1 : 5

NOTE:

1. BE SURE ALL PLUMBING IS TIGHT BEFORE DROPPING PRIMARY TANK IN CONTAINMENT. FITTINGS WILL NOT BE ACCESSIBLE AFTER INSTALLATION.
2. FISH OPEN BULKHEAD THROUGH CONTAINMENT WALL AND INSTALL CLAMPING NUT.
3. TEST PRIOR TO USE.

BULK HEAD CLAMPING NUT.

PROPRIETARY AND CONFIDENTIAL
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF <INSERT COMPANY NAME HERE>. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF <INSERT COMPANY NAME HERE> IS PROHIBITED.

		UNLESS OTHERWISE SPECIFIED:		NAME	DATE	CUSTOM ROTO-MOLDING, INC.	
		DIMENSIONS ARE IN INCHES		DRAWN	EBW	7-25-11	
		TOLERANCES:		CHECKED			TITLE:
		FRACTIONAL ±		ENG APPR.			TANK TO TANK PLUMBING
		ANGULAR: MACH ± BEND ±		MFG APPR.			SIZE
		TWO PLACE DECIMAL ±		Q.A.			DWG. NO.
		THREE PLACE DECIMAL ±		COMMENTS:			REV
		INTERPRET GEOMETRIC TOLERANCING PER:					
		MATERIAL					
		FINISH					
NEXT ASSY	USED ON	APPLICATION		DO NOT SCALE DRAWING		SCALE: 1:48 WEIGHT:	
						SHEET 1 OF 1	